

Refer to the Owner's Manual for your remote for more information.

Direct Code Entry

1. Press and hold the CODE SEARCH button until the red indicator flashes on, then release the CODE SEARCH button.
2. Press and release the desired Mode button (TV, VCR, etc.). The red indicator blinks; then stays lit.
3. Enter the 3 digit code from the code tables. Note: after a valid code entry, the red indicator turns off. For an invalid code, the red indicator flashes.
4. With your device on, press CHANNEL UP. If the device responds, no further programming is required. Note: If some buttons do not operate your device, try one of the other codes for your brand.

Code Search (by Device)

- If after trying "Direct Code Entry" or "Code Search (by Brand)" your device does not respond, or if your brand is not listed, try doing a device search of the code library for your code by following the steps below.
1. Manually turn on the device (TV, VCR, etc.) to be controlled.
 2. Press and hold the CODE SEARCH button until the red indicator stays on, then release the CODE SEARCH button.
 3. Press and release the desired Mode button (TV, VCR, etc.). The red indicator blinks, then stays lit.
 4. Press the CHANNEL UP button repeatedly (up to 300 times) until the device to be controlled changes channel. The red indicator blinks, then stays lit.
 5. Press and release MUTE to install the code.

Code Search (by Brand)

- Let's you search for a code for a specific Brand within the Code Library for a particular manufacturer:
1. Turn on the device (TV, VCR, etc.) to be controlled.
 2. Press and hold the CODE SEARCH button until the red indicator remains on, then release the CODE SEARCH button.
 3. Press and release the desired Mode button (TV, VCR, etc.). The red indicator blinks off once.
 4. Press and release the numeric button (0-9) corresponding to desired Manufacturer (see table below). Note: pressing "0" performs a full library search same as Device Library Code Search Method.
 5. Press the CHANNEL UP button (or POWER or PLAY (VCR only)) repeatedly until the device to be controlled changes channel.
 6. Press and release MUTE to install the code.

Guarde esta lista de códigos para futura referencia.

- Refiérase al procedimiento de programación de abajo y busque el código de 3 dígitos para su marca de TV, VCR, etc. Refiérase al Manual de Instrucciones de su control remoto para más información.
- Ingreso Directo de Códigos**
1. Oprima, sin soltar, el botón CODE SEARCH hasta que el indicador rojo permanezca encendido. Suelte el botón CODE SEARCH.
 2. Oprima y suelte el botón del la modalidad deseada (TV, VCR, etc.) El indicador rojo parpadeará y enseguida se queda encendido.
 3. Ingrese el código de 3 cifras de las tablas de códigos. Nota: después de ingresar un código, el indicador rojo se apagará. Cuando se ingresa un código inválido, el indicador rojo parpadeará.
 4. Con su aparato encendido oprima CHANNEL+. Si el aparato responde, ya no se requiere ninguna programación adicional. Nota: si algunos botones no hacen funcionar su equipo, trate uno de los demás códigos para su marca.
- Programación con CODE SEARCH (Búsqueda de códigos)**
1. Si su producto no responde después de haber intentado todos los códigos para su marca, o si su marca no está incluida en la lista, trate de buscar su código siguiendo estos pasos.
 1. Encienda manualmente el aparato (TV, VCR, etc.) que se habrá de controlar.
 2. Oprima, sin soltar, el botón CODE SEARCH hasta que el indicador rojo permanezca encendido. Suelte el botón CODE SEARCH.
 3. Oprima y suelte el botón de la modalidad deseada (TV, VCR, etc.). El indicador rojo parpadeará y enseguida permanece encendido.
 4. Oprima el botón CHANNEL+ repetidamente (hasta 300 veces) hasta que el aparato que se ha de controlar cambie de canal. El indicador rojo parpadeará y enseguida se queda encendido.
 5. Oprima y suelte el botón MUTE para fijar el código.

Busqueda de Códigos por Marcas

- Le permite buscar un código de una marca específica en la biblioteca de códigos para un fabricante en particular.
1. Encienda el aparato (TV, VCR, etc.) que se ha de controlar.
 2. Oprima sin soltar el botón CODE SEARCH (búsqueda de códigos) hasta que el indicador rojo permanezca encendido y enseguida suelte el botón.
 3. Oprima y suelte rápidamente el botón de la modalidad deseada (TV, VCR, etc.) El indicador rojo parpadeará una vez.
 4. Oprima y suelte el botón número (0-9) correspondiente al fabricante deseado (vea la tabla abajo). El indicador rojo parpadeará una vez y se apaga. Observe que al oprimar el "0", se efectúa una búsqueda completa de la biblioteca igual al Método de búsqueda de códigos.
 5. Oprima el botón CHANNEL+ (o POWER o PLAY (en la videocasetera solamente)) repetidamente hasta que el aparato que se ha de controlar cambie de canal.
 6. Oprima y suelte MUTE para fijar el código. La entrada del Método de búsqueda por marca está completo. Nota: Cuando se han buscado todos los códigos bajo una Marca, el indicador rojo parpadeará rápidamente durante 3 segundos.

Tabla de Búsqueda de marcas

Busque su marca en la columna correspondiente (TV, videocasetera, etc.). Fíjese cuál cifra (1, 2, 3, etc.) corresponde a su marca e ingrese al paso 4 de "Búsqueda de códigos por marca."

TV

ABEX	120	FUTURETEC	805 906
ADMIRAL	701 918	GATWAY	206
ADVENTURA	019	GE	002 006 007 018 103
AIKO	407	ADMIRAL	107 114 310 312 502 601
AIWA	121 221	ADVENTURA	704 803 806 810 901 911
ALLERON	706	AIKO	002 713
AMARK	603	AIWA	002 102 117 207
AMTRON	906	ALLERON	002 107 117 207
AKAI	801	AMARK	217 307 502 818
AMSTRAD	520	AMTRON	706 906
ANAM NATIONAL	104 805	AKAI	223 323
AOC	002 003 102 119	AMSTRAD	002 502
APEX	023	ANAM NATIONAL	002 016 116 216 315 410
ARCHER	603	AOC	502 507 515 519 607 701
AUDOVOX	906	APEX	707 710 715 815 902 915
BANG & OLUFSEN	620	ARCHER	807
BELCOR	002	AUDOVOX	807
BELL & HOWELL	506 601 701	BANG & OLUFSEN	713
BRADFORD	906	BELCOR	019
BROKSONIC	215 316	BELL & HOWELL	807
BROKWOOD	002	BRAFORD	002 007 102 103 107
CANDLE	002 019 402 502	BROKSONIC	002 502
CAPBHART	119	BROKWOOD	601 604 704 803 806 818
CELEBRITY	801	CANDLE	002 502
CENTURION	502	CAPBHART	007 107 108 308
CETRONIC	803	CELEBRITY	321 510 607 902
CHANGHONG	023	CENTURION	002 502 801
CITIZEN	002 112 319 402 407	CETRONIC	119
CLAIRSTONE	003	CHANGHONG	002 502
CLASSIC	023 805	CITIZEN	002 512 701 805 906
CLP CLASSIC	005 008 003	CLAIRSTONE	019 408 508
CLP CLASSIC	002 502 602	CLASSIC	203 208 219 306 317 417
COLORTYME	002 502	CLP CLASSIC	003 213 319 608 703 805 906
CONCERTO	002 502	CLP CLASSIC	601 701
CONCEJGE	713	COLORTYME	722 807
CONTECC/CONY	003 802	CONCERTO	002 501
CORNEA	805 902 906	CONCEJGE	601 701
CORONA	606	CONTECC/CONY	002 103 312 502
CROWN	805 906	CORNEA	506 512 601 704 807
CURTIS MATHEES	002 103 112 502	CORONA	002 009 109 118 309
DAEWOO	506 512 601 614 701 704 908	CROWN	002 502 719 807
DAEWOO	002 102 110 214	CURTIS MATHEES	601 701
DAYTRON	303 311 314 403 407 415	DAEWOO	002 502 507
DAYTRON	002 502	DAYTRON	002 115 502
DIMENISA	601 704	DAEWOO	506 601 701 706
DUMONT	002 713	DAYTRON	002 102 107 312 713 818
DYNASTY	805	DIMENISA	002 502 510 619
ELEKTRA	701	DUMONT	002 102 502 510 619
ELECTROBAND	003 801	DYNASTY	706 709 716 803 814
ELECTROHOME	002 502 803 901	ELEKTRA	601 701
ELITE	321	ELECTROBAND	901 918
EMERSON	002 003 004 005 104 105	ELECTROHOME	002 003 901
EMERSON	106 115 117 204 205 213 304 305 316	ELITE	906
EMERSON	319 405 421 502 505 506 519 520 604	EMERSON	002 120 502 512
EMERSON	605 705 706 804 805 903 904 905 906	EMERSON	002 102 110 111
ENVISION	002 502	EMERSON	502 510 602 719 901
FISHER	506 522 619 902	ENVISION	805
FUJITSU	321 706	FISHER	002 407 502
FUNAI	117 421 520 706 805 906	FUJITSU	407
		FUNAI	002 007 107 502

VCR

ADMIRAL	224
ADVENTURA	726
AIKO	826
AIWA	126 324 528 726
AKAI	027 235 335 424
AKAI	524 624 724 924
ALLEGRO	326 534 925
AMERICAN HIGH	130 226
ASHA	537
AUDIO DYNAMICS	025 436
AUDIOVOX	525
BELL & HOWELL	428
BEALIMARK	537
BROKSONIC	227 325 530 626 632
CALKX	025 026 525
CANDLE	537 625 725 825
CANNON	130 226 535 635
CARBHART	534
CARVER	330
CCE	230 826
CITIZEN	025 026 525 537
COLORTYME	625 725 825 836
COLT	230
CURTIS MATHEES	025 026 525 537
CURRA	230 426 525 537
CYBERNET	025 026 525 537
DAEWOO	626 726 826 926
DBX	025 436
DIMENISA	324 726
DYNATECH	027 525
ELECTROHOME	525
EMERSON	027 127 128 130 226 227
EMERSON	228 247 324 325 327 428 525 526
SYMPHONIC	117 421 520 904 906
TANDY	918
TATUNG	724 726 727 735 827 828 924 927
TECHNICS	025 029 032 129
TECHWOOD	328 330 426 428 928

Brand	TV	VCR/VIDEO	CABLE	SATELITE	CD/AUDIO
1	RCA, GE, Proscan	RCA, GE, Proscan	Scientific Atlanta	RCA, GE, Proscan	RCA, GE, Proscan
2	Zenith	Zenith, Aget Proscan	Zenith, General Instrument	Zenith, General Instrument	Zenith
3	Philips	Magnavox, Marantz, Philips, Sharp, Toshiba, Daewoo	Magnavox, Marantz, Philips, Sony, Panasonic, Sharp, Toshiba, Daewoo, Yamaha	Magnavox, Marantz, Philips, Sony, Panasonic, Sharp, Toshiba	Magnavox, Marantz, Philips, Sony, Panasonic, Sharp, Toshiba
4	Hitech, Sanyo, LG-Goldstar, Samsung, JVC, Mitsubishi, Sylvania, Fisher, Curtis-Matthes, Emerson	Hitech, Sanyo, LG-Goldstar, Samsung, JVC, Mitsubishi, Sylvania, Fisher, Curtis-Matthes, Emerson	Zenith, Gemini	Hitech, JVC, Samsung	Hitech, Sanyo, JVC, LG-Goldstar, Samsung, Mitsubishi, Sylvania, Fisher, Curtis-Matthes, Emerson, Odium, Pioneer, Tec, Nid, Kenwood, Yamaha, Denon, Onkyo
5	N/A	N/A	N/A	N/A	N/A
6	N/A	N/A	N/A	N/A	N/A
7	N/A	N/A	N/A	N/A	N/A
8	N/A	N/A	N/A	N/A	N/A
9	N/A	N/A	N/A	N/A	N/A
0	ALL	ALL	ALL	ALL	ALL

